

SAILOR 6248 VHF



SAILOR 6248 VHF

Installation manual

Document number: 98-133233-A

Release date: June 7, 2011

Disclaimer

Any responsibility or liability for loss or damage in connection with the use of this product and the accompanying documentation is disclaimed by Thrane & Thrane. The information in this manual is provided for information purposes only, is subject to change without notice and may contain errors or inaccuracies.

Manuals issued by Thrane & Thrane are periodically revised and updated. Anyone relying on this information should acquire the most current version e.g. from <http://www.thrane.com> or from the distributor.

Thrane & Thrane is not responsible for the content or accuracy of any translations or reproductions, in whole or in part, of this manual from any other source.

Copyright

© 2011 Thrane & Thrane A/S. All rights reserved.

Trademark Acknowledgements

- **SAILOR** is a registered trademarks of Thrane & Thrane A/S.
- Other product and company names mentioned in this manual may be trademarks or trade names of their respective owners.

Safety warning

The following general safety precautions must be observed during all phases of operation, service and repair of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture and intended use of the equipment. Thrane & Thrane assumes no liability for the customer's failure to comply with these requirements.

Ground the equipment

To minimise shock hazard, the SAILOR 6248 VHF unit must be connected to an electrical ground and the cable instructions must be followed.

RF exposure hazards and instructions

Your Thrane & Thrane radio set generates electromagnetic RF (radio frequency) energy when transmitting. To ensure that you and those around you are not exposed to excessive amounts of energy and thus to avoid health hazards from excessive exposure to RF energy, all persons must be at least 3ft (0.9 m) away from the antenna when the radio is transmitting.

Warranty limitation

IMPORTANT - The radio is a sealed waterproof unit (classified IPX8). To create and maintain its waterproof integrity it was assembled in a controlled environment using special equipment. The radio is not a user maintainable unit, and under no circumstances should the unit be opened except by authorized personnel. Unauthorized opening of the unit will invalidate the warranty.

Installation and service

Installation and general service must be done by skilled service personnel.

Record of revisions

Rev.	Description	Release Date	Initials
A	Original document	7 June 2011	UFO

Preface

Radio for occupational use

The SAILOR 6248 VHF fulfils the requirements of the EC Directive 1999/5/EC, Radio and Telecommunications TErminal Equipment and is intended for use in maritime environment.

SAILOR 6248 VHF is designed for *occupational use only* and must be operated by licensed personnel only.

SAILOR 6248 VHF is not intended for use in an uncontrolled environment by general public.

SAILOR 6248 VHF is designed for installation by a skilled service person.

Training information

The SAILOR 6248 VHF is designed for *occupational use only* and is also classified as such. It must be operated by licensed personnel only. It must only be used in the course of employment by individuals aware of both the hazards as well as the way to minimize those hazards

The radio is thus NOT intended for use in an uncontrolled environment by general public. The SAILOR 6248 VHF has been tested and complies with the FCC RF exposure limits for *Occupational Use Only*. The radio also complies with the following guidelines and standards regarding RF energy and electromagnetic energy levels including the recommended levels for human exposure:

- FCC OET Bulletin 65 Supplement C, evaluating compliance with FCC guidelines for human exposure to radio frequency electromagnetic fields.
- American National Standards Institute (C95.1) IEEE standard for safety levels with respect to human exposure to radio frequency electromagnetic fields, 3 kHz to 300 GHz
- American National Standards Institute (C95.3) IEEE recommended practice for the measurement of potentially hazardous electromagnetic fields - RF and microwaves.

Below the RF exposure hazards and instructions in safe operation of the radio within the FCC RF exposure limits established for it are described.

Warning

Your Thrane & Thrane radio set generates electromagnetic RF (radio frequency) energy when it is transmitting. To ensure that you and those around you are not exposed to excessive amounts of that energy (beyond FCC allowable limits for occupational use) and thus to avoid health hazards from excessive exposure to RF energy, FCC OET bulletin 65 establishes an Maximum Permissible Exposure (MPE) radius of 3 ft. (0.9m) for the maximum power of your radio (25W selected) with an half wave omni-directional antenna having a maximum gain of 3 dB (5.2dBi). This means all persons must be at least 3 ft. (0.9m) away from the antenna when the radio is transmitting.

Installation

1. An omni-directional antenna with a maximum power gain of 5.2 dBi must be mounted at least 9.6 ft. (2.9m) above the highest deck where people may be staying during radio transmissions. The distance is to be measured vertically from the lowest point of the antenna. This provides the minimum separation distance which is in compliance with RF exposure requirements and is based on the MPE radius of 3 ft. (0.9m) plus the 6.6 ft. (2m) height of an adult.
2. On vessels that cannot fulfil requirements in item 1, the antenna must be mounted so that its lowest point is at least 3 ft. (0.9m) vertically above the heads of people on deck and all persons must be outside the 3 ft. (0.9m) MPE radius during radio transmission.
 - Always mount the antenna at least 3ft (0.9m) from possible human access.
 - Never touch the antenna when transmitting
 - Use only authorized T&T accessories.
3. If the antenna has to be placed in public areas or near people with no awareness of the radio transmission, the antenna must be placed at a distance not less than 6 ft. (1.8m) from possible human access.

Failure to observe any of these warnings may cause you or other people to exceed FCC RF exposure limits or create other dangerous conditions.

Manual overview

This manual has the following chapters and appendices:

- *Introduction* contains a description of the VHF radio.
- *Installation* explains how to mount the VHF radio and how to connect accessories and external equipment.
- *Service & maintenance* contains support information including lists of accessories and a troubleshooting guide.
- Appendices with *Specifications & Approval* and *System configurations*.

Related documents

Title and description	Document number
SAILOR 6248 VHF, Installation guide	98-132282
SAILOR 6248 VHF User manual	98-131186
Moxa EtherDevice Switch EDS-205A/208A Series Hardware Installation Guide (SAILOR 6197 Ethernet Device)	1802002050023
Emergency call sheet	98-133795

Table Preface-1: Related documents

Online training for Thrane partners

As a Thrane Partner you have access to free of charge technical training in this SAILOR product covering installation, commissioning and repair.

For details on available training classes please consult the Thrane Academy at <http://extranet.thrane.com/Training.aspx>.

To learn more on CAN-bus as used with this product you may take the eLearning course "Introduction to CAN-bus" available at Thrane Academy at <http://extranet.thrane.com/Training.aspx>.

Table of contents

Chapter 1	Introduction	
	1.1 VHF radio	1-1
	1.2 Accessories available	1-4
Chapter 2	Installation	
	2.1 Unpacking and initial inspection	2-1
	2.2 Installing the VHF radio	2-2
	2.3 Connectors	2-10
	2.4 VHF antenna installation	2-17
	2.5 Accessories	2-19
Chapter 3	First-time power up	
	3.1 General use and navigation	3-1
Chapter 4	Service & maintenance	
	4.1 Contact for support	4-1
	4.2 Maintenance	4-1
	4.3 Troubleshooting guide	4-2
	4.4 Warranty and returning units for repair	4-4
Appendix A	Specifications & Approval	
	A.1 Transceiver unit SAILOR 6248 VHF	A-1
	A.2 SAILOR 6090 Power Converter 24–12 V	A-4
	A.3 Declaration of conformity	A-5
Appendix B	System configurations	
	B.1 System configuration examples	B-1
	B.2 Cable requirements	B-23
Glossary	Glossary-1
Index	Index-1

List of figures

Figure 1-1:	System configuration, example.....	1-6
Figure 2-1:	Desktop mounting	2-3
Figure 2-2:	Overhead mounting.....	2-4
Figure 2-3:	Mounting with the mounting bracket.....	2-5
Figure 2-4:	Drilling plan for the mounting bracket.....	2-5
Figure 2-5:	SAILOR 6248 VHF Dimension for flush mount	2-6
Figure 2-6:	Cutout for flush mount.....	2-6
Figure 2-7:	Flush mount	2-7
Figure 2-8:	SAILOR 6090 Power Converter, dimensions	2-8
Figure 2-9:	Connecting the SAILOR 6090 Power Converter.....	2-8
Figure 2-10:	SAILOR 6201 Handset with cradle.....	2-9
Figure 2-11:	Connections at the rear panel.....	2-11
Figure 2-12:	Antenna positioning	2-18
Figure 2-13:	SAILOR 6207 Connection Box for parallel handsets, mounting.....	2-20
Figure 2-14:	SAILOR 6207 Connection Box for parallel handsets, wiring	2-20
Figure 2-15:	SAILOR 6207 Connection Box for parallel handsets, diagram	2-21
Figure 2-16:	SAILOR 6208 Control Unit Connection Box, mounting.....	2-21
Figure 2-17:	SAILOR 6208 Control Unit Connection Box for parallel handsets, wiring	2-22
Figure 2-18:	SAILOR 6208 Control Unit Connection Box, diagram	2-22
Figure 4-1:	Fuse in the power connector	4-3
Figure 4-2:	Fuse in the SAILOR 6090 Power Converter.....	4-3
Figure B-1:	System configuration, DC Power Supply 6090.....	B-2
Figure B-2:	System configuration, AC Power Supply N1635	B-3
Figure B-3:	System configuration, DC Power Supply N420	B-4
Figure B-4:	System configuration, SAILOR 6201, VDR, loudspeaker and AUX OC	B-5
Figure B-5:	System configuration, SAILOR 6270 External Loudspeaker	B-6
Figure B-6:	System configuration, 2 SAILOR 6201 Handsets.....	B-7
Figure B-7:	System configuration, extra SAILOR 6201 Handset in SAILOR 6207.....	B-8
Figure B-8:	System configuration, SAILOR 6202 Hand Mic. and SAILOR 6201 Handset.....	B-9
Figure B-9:	System configuration, CAN bus, SAILOR 6204 CSM, close to the VHF radio	B-10
Figure B-10:	System configuration, CAN bus, SAILOR 6204 CSM, not close to the VHF radio	B-11
Figure B-11:	System configuration, CAN bus, SAILOR 6204 CSM, far from the VHF radio.....	B-12
Figure B-12:	System configuration, CAN bus, 2 SAILOR 6204 CSMs, close to VHF radio.....	B-13
Figure B-13:	System configuration, CAN bus, 2 SAILOR 6204 CSMs, far from VHF radio	B-14

Figure B-14: System configuration: CAN bus, 2 SAILOR 6204 CSMs, close to each other B-15

Figure B-15: System configuration: CAN bus, 2 SAILOR 6204 CSMs, close VHF, small bridge .. B-16

Figure B-16: System configuration: CAN bus, 2 SAILOR 6204 CSMs, in bridge wings B-17

Figure B-17: System configuration: CAN bus, 3 SAILOR 6204 CSMs, in bridge wings B-18

Figure B-18: System configuration: CAN bus, 4 SAILOR 6204 CSMs, in bridge wings B-19

Figure B-19: System configuration: CAN bus, 3 SAILOR 6204 CSMsB-20

Figure B-20: System configuration: CAN bus, 4 SAILOR 6204 CSMs B-21

Figure B-21: System configuration: Installation of LANB-22

List of tables

Table Preface-1:Related documents	-vi
Table 1-1: Accessories available.....	1-4
Table 2-1: Compass safe distance.....	2-3
Table 2-2: Pin allocation, connector at the front panel.....	2-10
Table 2-3: Pin allocation, ACC connector.....	2-12
Table 2-4: Pin allocation, AUX connector	2-13
Table 2-5: Pin allocation, CTRL connector	2-14
Table 2-6: Pin allocation, LAN connector.....	2-15
Table 2-7: Pin allocation, power.....	2-15
Table 2-8: Part numbers for accessories.....	2-19
Table 4-1: Troubleshooting guide	4-2
Table A-1: Technical specifications, part 1.....	A-1
Table A-2: Technical specifications, part 2.....	A-2
Table A-3: Technical specifications, SAILOR 6090	A-4
Table B-1: Cable overview	B-23
Table B-2: Cable specifications for cable 2.....	B-25
Table B-3: Cable specifications for cable 3.....	B-25
Table B-4: Cable specifications for cable 5.....	B-26
Table B-5: Cable specifications for cable 8 (AUX)	B-27
Table B-6: Cable specifications for cable 8 (CTRL).....	B-28
Table B-7: Pin allocation, LAN connector.....	B-29

Introduction

1.1 VHF radio

SAILOR 6248 VHF is approved to R&TTE, FCC and Industry Canada and is waterproof to the IPx8 and IPx6 standard. As part of the required safety equipment, use the SAILOR 6248 VHF in an emergency situation. However the best way to guarantee functionality in an emergency situation, is to use the radio in daily communication on board.



The VHF radio is a simplex/semi duplex VHF radio. It is designed with an easy-to-use menu-driven setup. You use the soft-keys and the keypad to enter the desired functions, you browse and select a setting using the right selection knob. The large display can be customized for optimum readability and visibility both day and night with several color themes.

The VHF radio can replay the last 240 s of received voice messages. This is a useful feature to minimize misunderstandings and to record messages when the radio is unattended.

With SAILOR connection boxes the VHF radio connects easily to external equipment like additional handsets, water proof hand microphones, control speaker microphone or external speaker. The Ethernet interface enables the VHF radio to be connected to ThrelINK for remote control and service updates.

For a list of accessories available for the VHF radio see *Accessories available* on page 1-4 and *Part numbers for accessories* on page 2-19 and check with your nearest distributor.

1.1.1 Controls on the front plate




1. Loudspeaker.
2. Four soft keys with function title in the display.
3. Large display.
4. Keys 0 to 9 to enter numbers or text.
5. **DW** button to toggle the watch function (dual or triple).
6. **16/C** quick selection key for channel 16 and the programmed call channel.
7. Connector for Handset or Handmicrophone.
8. Squelch control to mute background noise.
9. Volume knob with key-press function for volume control and power on/off.
10. Selector and dim knob with key-press function for general operation, display color selection and dimming.
11. **1W** button to toggle between high and low power.
12. Replay button to play back up to 240 s voice message.

1.1.2 SAILOR 6248 VHF display

The picture shows the display after start-up. The display holds various fields of information, depending on the currently selected function.

1. Functions you can select with the soft keys.
2. Current working channel.
3. **System property icons** with information relevant for the currently selected functions.
4. Channel properties next to the currently selected VHF channel (if any).
5. **Service line** containing current temporary information relevant for the current channel or function.
6. Current state: RX or TX.



For a detailed description of the information shown for each of the functions available see the user manual.

1.2 Accessories available

Accessory	Description
SAILOR 6201 Handset with cradle (additional)	One SAILOR 6201 Handset with cradle is included in the delivery of the SAILOR 6248 VHF. You can connect another 2 SAILOR 6201 Handsets. 
SAILOR 6203 Handset with cradle	SAILOR 6203 Handset with cradle, waterproof to IPx6. 
SAILOR 6202 Hand Microphone	You can use the SAILOR 6202 (waterproof to IPx6 and IPx8) Hand Microphone instead of the handset. 
SAILOR 6204 Control Speaker Microphone	With the SAILOR 6204 Control Speaker Microphone you can control the VHF functions of the SAILOR 6248 VHF. 
SAILOR 6207 Connection Box for parallel handsets	The SAILOR 6207 Connection Box including Connection Cable 406209-941 is used for easy installation of several SAILOR 6201/03 Handsets. 
SAILOR 6208 Control Unit Connection Box	The SAILOR 6208 Connection Box including Connection Cable 406208-941 is used for easy installation of external equipment and accessories: <ul style="list-style-type: none"> • Max. 4 SAILOR 6204 Control Speaker Microphones • VDR • SAILOR 6270 External loudspeaker 


Table 1-1: Accessories available

Accessory	Description
Connection cables	<p>5m connection cable for bulkhead mount: Use this cable in installations where the SAILOR 6201 or 6203 Handset is not connected directly to the SAILOR 6248 VHF, but located in a different position (part number: 406204-940).</p> <p>5m Connection cable, 1x10 pole: Use this cable in installations when connecting external equipment to the SAILOR 6248 VHF. This cable is included in the SAILOR 6207 Connection Box for parallel handsets (part number: 406207-941).</p> <p>5 m Connection cable for SAILOR 6204 Control Speaker Microphone, 1x12 pole (part number: 406204-940).</p>
SAILOR 6270 External loudspeaker	<p>If you need an additional external loudspeaker you can connect a SAILOR 6270 Loudspeaker. It provides 6 W output power.</p> 
SAILOR 6197 Ethernet Switch	<p>The SAILOR 6197 Ethernet Switch is used in installations with ThraneLINK. The Ethernet switch has 5 ports.</p> 
SAILOR 6090 Power Converter 24 V to 12 V DC	<p>The SAILOR 6090 Power Converter is used to provide 12 V DC for the SAILOR 6248 VHF from a 24 V DC power source.</p> 

Table 1-1: Accessories available (Continued)

1.2.1 System configuration – example

The SAILOR 6248 VHF can be customized to suit your installation. The following illustration is one example of a system. For further configuration examples see Appendix B, *System configurations*.



99-133232-A

Figure 1-1: System configuration, example

Installation

In this chapter you find information and guidelines for:

- *Unpacking and initial inspection*
- *Installing the VHF radio*
- *Connectors*
- *VHF antenna installation*
- *Part numbers for accessories*

2.1 Unpacking and initial inspection

The following items are included in the delivery of a SAILOR 6248 VHF:

- SAILOR 6248 VHF
- SAILOR 6201 Handset with cradle
- User manual
- Installation guide
- Emergency call sheet
- Mounting bracket with two knobs
- Connectors for cables
- Power cable, fittings and fuses
- Packaging material
- Kit for flush mount installation, including gasket
- SAILOR 6090 Power Converter 24 to 12 V

2.1.1 Initial inspection

Inspect the shipping carton immediately upon receipt for evidence of damage during transport. If the shipping carton is severely damaged or water stained, request that the carrier's agent be present when opening the carton. Save the carton packing material for future use.



WARNING! To avoid electric shock, do not apply power to the system if there is any sign of shipping damage to any part of the front or rear panel or the outer cover. Read the safety summary at the front of this manual before installing or operating the system.

After unpacking the system, inspect it thoroughly for hidden damage and loose components or fittings. If the contents are incomplete, if there is mechanical damage or defect, or if the system does not work properly, notify your dealer.

2.2 Installing the VHF radio

You can mount the VHF radio as a desktop, overhead or flush-mounted unit integrated in the instrument panel.

Provide space enough to access the front panel connectors and for installing a cradle for the speaking device.

Provide **at least 120 mm space at the back** of the SAILOR 6248 VHF radio to allow free air circulation and for cable access.

Cable requirements

All cables attached to the SAILOR 6248 VHF must be shielded. Every shield should have a low impedance connection to an electrical ground.

Before using the SAILOR 6248 VHF for the first time, check that all cables are correctly wired and fastened.

Compass safe distance

Make sure that the VHF radio is far enough from any magnetic compass to avoid influence of the loudspeaker magnet on the compass reading. See the following table

for the safe distance after magnetization between the nearest point of the device and the centre of the compass at which it will produce a deviation of 0.3° .

Device	Compass safe distance
SAILOR 6248 VHF	0.85 m
SAILOR 6201 and 6203 Handset with cradle	0.95 m
SAILOR 6090 Power Converter 24 V – 12 V	0.15 m
SAILOR 6207 Connection Box for parallel handsets	0.45 m
SAILOR 6208 Control Unit Connection Box	0.45 m

Table 2-1: Compass safe distance

2.2.1 SAILOR 6248 VHF with U mounting bracket

The mounting bracket and two knobs are included in the delivery.

Desktop mounting




Figure 2-1: Desktop mounting

Overhead mounting





Figure 2-2: Overhead mounting

Mounting with U mounting bracket

To mount the VHF radio as tabletop, do as follows:

1. Find a suitable location for the VHF radio. Check that the space is wide/deep enough to accommodate the VHF radio.
2. Fasten the bracket with 4 screws (included in the delivery.)
3. Insert the VHF radio in the bracket and fasten it with the two knobs.

- The display of the VHF radio should be at an angle of approximately 90° to your line of sight when operating it.



99-131865

Figure 2-3: Mounting with the mounting bracket




Figure 2-4: Drilling plan for the mounting bracket

2.2.2 SAILOR 6248 VHF for flush mount

You can mount the VHF radio to a flat surface, e.g. an instrument panel. The flush mount installation kit is included in the delivery.




Figure 2-5: SAILOR 6248 VHF Dimension for flush mount




Figure 2-6: Cutout for flush mount

Important The scaling in the above drawing is not 1:1. Consequently do not attempt to use a print or copy of this page without checking the dimensions.

1. Find a suitable location for the VHF radio. Check that the space is deep enough to accommodate the VHF radio and an additional min. 120 mm space for cable entry.
2. Keep free distance to allow free air circulation around the VHF radio and to allow sufficient space for access to cables, see the drawing on this page.
3. Cut out the hole for the VHF radio where you want to mount it. Use the cutting template in the installation guide.
4. Mount the 4 square nuts M4 in the cabinet, ensure that they are placed correctly so it is possible to screw in the M4x45 screws.

5. Ensure that the flush mount gasket is placed correctly on the VHF radio.
6. Before mounting the VHF radio be aware that the surface is plane and rigid. If the surface is not plane and/or rigid (stiff) remove the gasket and seal with silicone sealant between the VHF radio and the surface.
7. Slide the VHF radio in the cut-out. Place the flush mount bracket and fasten it with the 4 screws M4x45. Make sure the torque does not exceed 1Nm when fastening the screws.

Note Only use screws supplied with the kit for flush mounting.





Figure 2-7: Flush mount

Note Firmly tie back and secure any wires not used to avoid the possibility for mutual shorting or shorting to ground.

2.2.3 SAILOR 6090 Power Converter




Figure 2-8: SAILOR 6090 Power Converter, dimensions




Figure 2-9: Connecting the SAILOR 6090 Power Converter

2.2.4 SAILOR 6201 Handset with cradle




Figure 2-10: SAILOR 6201 Handset with cradle

2.3 Connectors

2.3.1 Connector at the front panel for handset or handmicrophone


Use the connector at the front of the SAILOR 6248 VHF to connect a SAILOR 6201 Handset. You may also connect a waterproof SAILOR 6203 Handset or SAILOR 6202 Handmicrophone.

Connector type: Circular connector, 10pin, male.

Connection cable with plug, part number 406209-941.

Pin assignment: Connector front view on the VHF radio.

Panel lock, 10 pin male



Pin	Description	Wire color
1	Not connected	Brown
2	Not connected	Blue
3	Not connected	White
4	Not connected	Green
5	Mic+	Yellow
6	Earpiece	Grey
7	Hook_PTT	Pink
8	Battery V +10.8 – 15.6 VDC	Red
9	Internal GND = - Battery	Black
10	Internal GND = - Battery	Orange – SCREEN (Drain)

Table 2-2: Pin allocation, connector at the front panel

2.3.2 Connectors at the rear panel




Figure 2-11: Connections at the rear panel

1. *ACC connector* for accessories
2. *AUX connector* for VDR, external speaker
3. *Power connector PWR FUSE* with fuse 10 A mini ATO
4. *Ground stud* for grounding
5. *ANT connector* for VHF antenna
6. *CTRL connector*
7. *Ethernet connector: LAN*

2.3.3 ACC connector


Use the connector marked **ACC** to connect a SAILOR 6201 Handset. You may also connect a waterproof SAILOR 6203 Handset or SAILOR 6202 Handmicrophone.

Connector type: Circular connector, 10pin, male.

Panel lock, 10 pin male

Connection cable with plug, part number 406209-941.

Pin assignment: Connector front view on the VHF radio.



Pin	Description	Wire color
1	–	Brown
2	–	Blue
3	–	White
4	–	Green
5	Mike 2 / Line in	Yellow
6	EAR 2 / Line out	Grey
7	Hook_PTT	Pink
8	Battery supply when radio is on	Red
9	Internal GND = - Battery	Black
10	Internal GND = - Battery	Orange – SCREEN (Drain)

Table 2-3: Pin allocation, ACC connector


2.3.4 AUX connector

This connector is used to connect VDR and external speaker.

Connector type: Circular connector, 12pin.

Connection cable with plug, part number 406208-941.

Pin assignment: Connector front view on the VHF radio:



Pin	Description	Wire color
1	Shield (GND)	Brown
2	Lo Power Forced control	Blue
3	–	White
4	–	Green
5	AUX OC	Yellow
6	–	Grey
7	–	Pink
8	-Battery	Red
9	External Speaker +	Black
10	External Speaker -	Orange
11	VDR+ Mixed RX/TX for record	Violet
12	VDR- Mixed RX/TX for record	Cyan

Table 2-4: Pin allocation, AUX connector


2.3.5 CTRL connector

This connector is used to connect a SAILOR 6204 Control Speaker Microphone or SAILOR 6208 Connection Box.

Connector type: Circular connector, 12pin.

Connection cable with plug, part number 406208-941.

Pin assignment: Connector front view on the VHF radio:



Pin	Description	Wire color
1	GND for cable screen	Brown
2	Internal GND-- Battery	Blue
3	Battery supply when radio is on	White
4	Battery supply when radio is on	Green
5	CAN+	Yellow
6	CAN-	Grey
7	Internal GND = - Battery	Pink
8	On/off from Control Speaker Microphone	Red
9	RX out +	Black
10	RX out -	Orange
11	TX in +	Violet
12	TX in -	Cyan

Table 2-5: Pin allocation, CTRL connector

2.3.6 Ethernet connector: LAN

There is one Ethernet (10/100 MB) connector on the rear panel, it is marked LAN.

Connector type: RJ-45 female, shielded

Pin number	Pin function	Wire color
1	Tx+	white/orange
2	Tx-	orange
3	Rx+	white/green
4	Not connected	blue
5	Not connected	white/blue
6	Rx-	green
7	Not connected	white/brown
8	Not connected	brown




Table 2-6: Pin allocation, LAN connector

2.3.7 Power connector PWR FUSE

The DC Power input connects to a DC supply with 12 DC nominal (10.8 to 15,6 V DC). The connector has a 10 A fuse. The interface also has a “remote on/off” function for a remote 24 V – 12 V DC Power Converter.

Connector type: LTW Power

Fuse: 10 A mini ATO

To help extract the fuse you can order a fuse puller in the **ESHOP** at <http://extranet.thrane.com/>.

Pin-out

The figure and table below show the connector outline, pin assignments and wire color in the power cable delivered with the SAILOR 6248 VHF.

Pin	Pin function	Wire color
1	DC+ (10.8 - 15,6 V DC)	Red
2	DC- (0 V DC)	Blue
3	Remote on/off	Yellow

Table 2-7: Pin allocation, power

Connecting DC power

- Connect DC+ (red wire) to DC out + from your DC supply.
- Connect DC- (blue wire) to DC out - from your DC supply.

Connect the yellow wire in the power cable to use the Remote on/off function.

2.3.8 ANT connector for VHF antenna

Use the connector marked **ANT** to connect the VHF antenna to the radio with a 50 Ohm coaxial cable with low loss, e.g. RG214. Install a PL259 plug at the cable end.

Place the antenna as high and clear of obstructions as possible. Make sure that the horizontal distance to metal parts is minimum 1.5 m (5 ft.).

Connector type: female SO239 for PL259 plug.

For more information about VHF antenna installation see *VHF antenna installation* on page 2-17.

2.3.9 Ground stud for grounding

Important | You must connect the Ground stud to ship ground.

The ground stud is located on the rear panel and is used to connect a ground wire for grounding the SAILOR 6248 VHF. To connect the SAILOR 6248 VHF to ship ground, do as follows:

1. Connect a ground cable of > 1 m length and > 4 mm² cross section to the Ground stud located between the DSC ANT and ANT connector and fasten it with the wing nut.
2. Connect the other end of the cable to ship ground. Make the cable as short as possible.

2.4 VHF antenna installation

The SAILOR 6248 VHF must be installed with one antenna for VHF RX/TX communication. You can install all commonly available 50 Ohm antennas covering the appropriate frequency range and providing a VSWR less than 1.5 over this range.

For further details on equipment and antenna installation, see IMOCOMSAR/Circ. 32, GUIDELINES FOR THE HARMONIZATION OF GMDSS REQUIREMENTS FOR RADIO INSTALLATIONS ON BOARD SOLAS SHIPS.

2.4.1 Cable requirements

Connect the antennas using a low loss type 50 Ohm coaxial cable, e.g. good quality RG214 or better. IMO-COMSAR/Circ. 32 recommends the use of a double screened type cable (like e.g. RG214) with a maximum insertion loss of 3dB across the antenna cable installation.

The maximum antenna cable length in the installation depends on the quality of the cable, i.e. the specified attenuation (dB/m) of the cable of choice at the high end of the VHF frequency band. As a rule of thumb the cable length using e.g. RG214 coaxial cable should not exceed 25 m.

2.4.2 VHF RX/TX antenna

In installations with two or more VHF radios it is important to ensure the optimum performance of these by carefully selecting the antenna positions for both radios. It is recommended to maximize the RF attenuation between the VHF RX/TX antennas in the installation. You can ensure this by not having the RX/TX antennas positioned at the same horizontal level, i.e. the RX/TX antennas for each radio must be installed at shifted elevations as shown in the following drawing.

If sufficient vertical distance between two or more such antennas cannot be achieved, the horizontal distance between them is increasingly important for optimum performance. If there is hardly any vertical separation ensure that there is a minimum of 5 m horizontal distance between any RX/TX antennas in the installation.

To minimize any increase in VSWR of the VHF RX/TX antenna, install the antenna at a vertical distance of at least 2 m to any other mast, pole or other RF antennas. Keep VHF

antennas as far away as possible from antenna main beam of any radar and satellite equipment.




Figure 2-12: Antenna positioning

2.5 Accessories

2.5.1 Part numbers for accessories

The following accessories are available for the SAILOR 6248 VHF:

Part number	Accessories available
406201A	SAILOR 6201 Handset with cradle (additional)
406202A	SAILOR 6202 Hand Microphone
406203A	SAILOR 6203 Handset Waterproof
406204A	SAILOR 6204 Control Speaker Microphone
406207A	SAILOR 6207 Connection Box with Cable 406209-941
406208A	SAILOR 6208 Connection Box with Cable 406208-941
406209-940	Connection Cable for bulkhead mount, 5 m, 1-x10 pole
406209-941	Connection Cable, 5 m, 1x10 pole
406204-940	Cable for SAILOR 6204 Control Speaker Microphone
406270A	SAILOR 6270 Loudspeaker
406197A	SAILOR 6197 Ethernet Switch
406090A	SAILOR 6090 Power Converter 24 V – 12 V

Table 2-8: Part numbers for accessories

2.5.2 Connection box SAILOR 6207

The **SAILOR 6207 Connection Box** is used to connect further SAILOR 6201 Handsets. For wiring and cabling details see *System configuration examples* on page B-1.





Figure 2-13: SAILOR 6207 Connection Box for parallel handsets, mounting



Description	Pin	Wire color
NC	1	Brown
NC	2	Blue
NC	3	White
NC	4	Green
Mike 2 / Line in	5	Yellow
Ear 2 / Line out	6	Grey
Hook_PTT	7	Pink
Bat_SW Supply voltage when on	8	Red
Internal GND = - Battery	9	Black
Internal GND = - Battery	10	Orange
Internal GND = - Battery	11	SCREEN (Drain)
	12	NC

Cable part no. 406209-941

To ensure galvanic separation of battery supply from ship's ground, the cable screens of the ACC cables **MUST** not touch any part of the metallic parts of the SAILOR 6207 Connection Box. Connect the screens only to the pins at the terminals.

Figure 2-14: SAILOR 6207 Connection Box for parallel handsets, wiring




Figure 2-15: SAILOR 6207 Connection Box for parallel handsets, diagram

2.5.3 Connection box SAILOR 6208

The **SAILOR 6208 Connection Box** is used to connect SAILOR 6204 Control Speaker microphones and other auxiliary equipment. For wiring and cabling details see *System configuration examples* on page B-1.




Figure 2-16: SAILOR 6208 Control Unit Connection Box, mounting




Figure 2-17: SAILOR 6208 Control Unit Connection Box for parallel handsets, wiring
 Terminate the last SAILOR 6208 on the CAN bus (furthest away from the transceiver).




Figure 2-18: SAILOR 6208 Control Unit Connection Box, diagram

First-time power up


3.1 General use and navigation

The tasks needed to be performed during installation are described below. See the SAILOR 6248 VHF User manual for instructions how to operate and set up the VHF radio.

3.1.1 Power on and volume in handset and speaker

The VHF radio has a dual-function on/off knob for power on/off and volume control.



- To power on the VHF radio press the on/off knob.
- To power off the VHF radio, press and hold the on/off knob and follow the instructions in the display.
- To adjust the speaker volume, turn the volume knob (clockwise = louder, counter clockwise = softer, until muted). When muted,  is shown in the display.
- To adjust the volume of the handset earpiece see the SAILOR 6248 VHF *User manual*.

3.1.2 Working channel and changing settings

Use the **selector knob** to browse and select:



- To browse and select **settings**, turn the selector knob and press for accept.
- To select a **working channel** use the selector knob or enter the channel number using the keypad.

Service & maintenance

4.1 Contact for support

Contact your authorized dealer for technical service and support of the VHF radio. Before contacting your authorized dealer you can go through the troubleshooting guide to solve some of the most common operational problems.

4.2 Maintenance

4.2.1 Preventive maintenance

Maintenance of the SAILOR 6248 VHF can be reduced to a maintenance check at each visit of the service staff. Inspect the radio for mechanical damages, salt deposits, corrosion and any foreign material. Due to its robust construction and ruggedness the radio has a long lifetime. Anyway it must carefully be checked at intervals not longer than 12 months - dependent on the current working conditions.

Salt deposits

In case the equipment has been exposed to sea water there is a risk of salt crystallization on the keys and knobs and they may become inoperable. Clean the VHF radio and speaker microphones with fresh water.

4.2.2 Error messages and warnings

Errors and warning messages are shown in the display and are read-only.

4.3 Troubleshooting guide

Action	Symptom	Remedy
The radio will not turn on	The display is empty.	<p>Check if power is present.</p> <p>Check fuse which is placed in the power connector.</p> <p>Check performance of power supply if connected to one.</p>
No communication	The loudspeaker is mute.	<p>Check the antenna installation.</p> <p>Check antenna cable.</p> <p>Check handset/Handmicrophone and cable.</p>
Handset configuration	No sound in earpiece	The earpiece volume may be configured to OFF. See section <i>Controller setup in the user manual</i> on how to adjust the earpiece volume of the handset.
Device failure		<p>If any of the checks and tests described in this section do not assist in resolving the difficulties experienced in the operation and/or performance of the VHF installation, a fault may have developed in the VHF radio itself.</p> <p>When contacting an authorized Thrane & Thrane representative be sure to provide as much information as possible describing the observed behavior - also including the type of the VHF radio, its serial number, and software release version (both found in the setup menu Controller Setup).</p>
WARNING: POWER SUPPLY LOST CONTACT	Power supply status cannot be monitored.	<p>In Setup, Power Supply, set Monitor to disabled.</p> <p>You can only monitor the power supply if the radio is powered by a SAILOR 6081 Power Supply Unit and Charger.</p>

Table 4-1: Troubleshooting guide

4.3.1 Replacing the fuse in the power connector

One fuse is installed in the power connector. If the fuse is blown, do as follows:

1. Track down why the fuse was blown and solve the problem.
2. Take out the old fuse.
3. Insert the new fuse. The fuse rating is 10 A T.




Figure 4-1: Fuse in the power connector

4.3.2 Replacing the fuse in the SAILOR 6090 Power Converter

One fuse is installed in the SAILOR 6090 Power Converter. If the fuse is blown, do as follows:

1. Track down why the fuse was blown and solve the problem.
2. Take out the old fuse.
3. Insert the new fuse. The fuse rating is 10 A T.




Figure 4-2: Fuse in the SAILOR 6090 Power Converter

4.4 Warranty and returning units for repair

Should your Thrane & Thrane product fail, please contact your dealer or installer, or the nearest Thrane & Thrane partner. You will find the partner details on www.thrane.com where you also find the Thrane & Thrane Self Service Center web-portal, which may help you solving the problem.

Your dealer, installer or Thrane & Thrane partner will assist you whether the need is user training, technical support, arranging on-site repair or sending the product for repair.

Your dealer, installer or Thrane & Thrane partner will also take care of any warranty issue.

4.4.1 Repacking for shipment

Should you need to send the product for repair, please read the below information before packing the product.

The shipping carton has been carefully designed to protect the SAILOR 6248 VHF and its accessories during shipment. This carton and its associated packing material should be used when repacking for shipment. Attach a tag indicating the type of service required, return address, part number and full serial number. Mark the carton FRAGILE to ensure careful handling.

Note | Correct shipment is the customer's own responsibility.

If the original shipping carton is not available, the following general instructions should be used for repacking with commercially available material.

1. Wrap the defective unit in heavy paper or plastic. Attach a tag indicating the type of service required, return address, part number and full serial number.
2. Use a strong shipping container, e.g. a double walled carton of 160 kg test material.
3. Protect the front- and rear panel with cardboard and insert a 7 cm to 10 cm layer of shock-absorbing material between all surfaces of the equipment and the sides of the container.
4. Seal the shipping container securely.
5. Mark the shipping container FRAGILE to ensure careful handling.

Failure to do so may invalidate the warranty.

Specifications & Approval

A.1 Transceiver unit SAILOR 6248 VHF

Item	Specification
Weight SAILOR 6248 VHF	< 1.50 kg (3.3 lbs) approximately
Box weight SAILOR 6248 VHF	3.8 kg (8.4 lbs) approximately, including SAILOR 6201 Handset and wall mount cradle, SAILOR 6090 Power Converter and Installation and user manual in box.
Dimensions	<p>Height: Outer dimension 107 mm, hole height for flush mount 89 mm</p> <p>Width: Outer dimension 241 mm, hole width for flush mount 227 mm</p> <p>Depth: Outer dimension from front of knobs 132 mm, depth for flush mount 94 mm</p>
Operating temperature	-25°C to 55°C (5°F to 131°F)
Storage temperature	-30°C to 80°C (-22°F to 176°F)
Power supply	12 VDC Nominal (10,8- 15,6 VDC)
Current consumption	Max. 7 A
Current consumption at 12 VDC without any accessories connected	RX: 0.5 A TX: 5 A
Current consumption at 12 VDC with all accessories connected	RX: 0.7 A TX: 7 A
Frequency range	TX: 156,000 MHz – 157,425 MHz, RX: 156,000 MHz – 163.425 MHz

Table A-1: Technical specifications, part 1

Item	Specification
Channel spacing	12.5 kHz and 25 kHz, all international maritime channels
Number of P channels	The radio may be programmed with up to 100 private channels that can be managed in all channel modes.
Modulation 25 kHz 12.5 kHz	16K0G3E 8K05G3E
Antenna	50 Ohm antenna, 50 Ohm female S0239 for PL259 plug
Water ingress	IPx8 and IPx6 all over. For flush-mount installations a sealing gasket is included in the delivery.
Transmitter	
Transmit power	Hi/Lo: 25 W and 1 W
RF output power	High: 25 W +0 dB / - 1.5 dB Low: 1 W +0 dB / - 1.5 dB
RF output power, Canada	High: 21 W ±0.75 dB Low: 0.8 W ±0.75 dB
Frequency error	Below 500 Hz
Adjacent channel power	Below 75 dB
Conducted spurious emission	Below 0.25 µW
Distortion	Below 3%
S/N ratio	Better than 46 dB
Receiver	
Sensitivity	< -119 dBm typically @ 20 dB SINAD CCITT weighted
LF power	Built-in loudspeaker: 6 W (at 5 kHz dev./1 kHz tone) External loudspeaker: 6 W / 8 Ohm
Distortion	Below 5%

Table A-2: Technical specifications, part 2

Item	Specification
S/N ratio	Better than 43 dB
Spurious emissions	Below 2 nW
Spurious response rejection	More than 74 dB
Intermodulation response	More than 73 dB
Co-channel rejection	Better than -10 dB
Adjacent channel selectivity	More than 74 dB
Blocking level	More than 94 dB μ V

Table A-2: Technical specifications, part 2 (Continued)

A.2 SAILOR 6090 Power Converter 24–12 V

Item	Description
Weight	300 g
Dimensions	Height: 33 mm Width: 190 mm Depth: 85 mm
Operating temperature	-25°C to 55°C (5°F to 131°F)
Storage temperature	-30°C to 80°C (-22°F to 176°F)
Input voltage	21–32 VDC
Output voltage	12.5 VDC
Output current (max.)	8 A

Table A-3: Technical specifications, SAILOR 6090

A.3 Declaration of conformity

The SAILOR 6248 VHF complies with the specifications of EC directive 1999/5/EC concerning Radio & Telecommunications Terminal Equipment, enclosed in electronic copy on the next page.

Thrane & Thrane

Thrane & Thrane A/S Declaration of Conformity with R&TTE Directive

The undersigned of this letter declares that the following equipment complies with the specifications of EC directive 1999/5/EC concerning Radio & Telecommunications Terminal Equipment.

Equipment included in this declaration

TT-6248A	SAILOR 6248 VHF transceiver	PN = 406248A
TT-6201A	SAILOR 6201 Handset	PN = 406201A
TT-6203A	SAILOR 6203 Handset WP	PN = 406203A
TT-6202A	SAILOR 6202 Hand microphone	PN = 406202A
TT-6207A	SAILOR 6207 Accessory Connection box	PN = 406207A
TT-6208A	SAILOR 6208 Control Unit Connection box	PN = 406208A

Equipment Applicability

SAILOR 6248 is a simplex/semi-duplex VHF radiotelephone designed for maritime communication within the frequency range 156.000 MHz to 163.425 MHz.

Declaration

SAILOR 6248 conforms to the RTTE directive with respect to
 Article 3(1)(a) the protection of health and safety
 Article 3(1)(b) electromagnetic compatibility requirements
 Article 3(2) effective use of the spectrum and avoidance of harmful interference

Which is shown by conforming to EU harmonized standards

EN 300 162-2 V1.2.1,
 EN 300 698-2 V1.2.1,
 EN 60945 ed. 4,
 EN 60950-1 ed. 2.

Manufacturer

Thrane & Thrane A/S Lundtoftegårdsvej 93D, DK-2800 Kgs. Lyngby, Denmark
 Porsvej 2, DK-9200 Aalborg SV, Denmark

Place and Date

Aalborg, 16th May 2011



Chief Financial Officer
 Svend Åge Lundgaard Jensen

CE 0470

Doc. no TT99-133814-A

Thrane & Thrane A/S · Lundtoftegårdsvej 93D · DK-2800 Kgs. Lyngby · Denmark
 T +45 39 55 88 00 · F +45 39 55 88 88 · info@thrane.com · www.thrane.com
 Bank: Danske Bank · Comp. reg.: 65 72 46 18 · VAT: DK-20 64 64 46



System configurations

This appendix lists selected examples of system configurations.

For an overview and specifications of the cables needed see **Cable requirements on page B-23**.

Note For installation of the connection boxes see *Connection box SAILOR 6207* on page 2-20 and *Connection box SAILOR 6208* on page 2-21.

B.1 System configuration examples

The following list shows system configurations, with additional handsets, alarm panels, connection boxes and cable information.

1. *How to connect a DC Power Supply 6090*
2. *How to connect an AC Power Supply N163S*
3. *How to connect a DC Power Supply N420*
4. *How to install an additional SAILOR 6201, VDR, loudspeaker & AUX OC*
5. *How to install a SAILOR 6270 External Loudspeaker*
6. *How to install 2 extra SAILOR 6201 Handsets*
7. *How to install an extra SAILOR 6201 Handset in SAILOR 6207*
8. *How to install a SAILOR 6202 Hand Microphone and an extra SAILOR 6201*
9. *How to install a CAN bus and a SAILOR 6204 CSM close to the VHF*
10. *How to install a CAN bus with a SAILOR 6204 CSM not close to the VHF radio*
11. *How to install a CAN bus with a SAILOR 6204 CSM far from the VHF radio*
12. *How to install a CAN bus with 2 SAILOR 6204 close to the VHF*
13. *How to install a CAN bus and 2 SAILOR 6204 CSM far from the VHF*
14. *How to install a CAN bus with 2 SAILOR 6204 CSMS close to each other*
15. *How to install a CAN bus with 2 SAILOR 6204 CSMS close to VHF on a small bridge*
16. *How to install a CAN bus with 2 CSMS in bridge wings*
17. *How to install a CAN bus with 3 CSMS in bridge wings*
18. *How to install a CAN bus with 4 CSMS in bridge wings*

- 19. How to install a CAN bus with 3 SAILOR 6204 CSMs
- 20. How to install a CAN bus with 4 SAILOR 6204 CSMs
- 21. How to install LAN

B.1.1 How to connect a DC Power Supply 6090




Figure B-1: System configuration, DC Power Supply 6090

B.1.2 How to connect an AC Power Supply N163S




Figure B-2: System configuration, AC Power Supply N163S

B.1.3 How to connect a DC Power Supply N420




Figure B-3: System configuration, DC Power Supply N420

B.1.4 How to install an additional SAILOR 6201, VDR, loudspeaker & AUX OC




Figure B-4: System configuration, SAILOR 6201, VDR, loudspeaker and AUX OC

B.1.5 How to install a SAILOR 6270 External Loudspeaker




Figure B-5: System configuration, SAILOR 6270 External Loudspeaker

B.1.6 How to install 2 extra SAILOR 6201 Handsets




Figure B-6: System configuration, 2 SAILOR 6201 Handsets

B.1.7 How to install an extra SAILOR 6201 Handset in SAILOR 6207




Figure B-7: System configuration, extra SAILOR 6201 Handset in SAILOR 6207

B.1.8 How to install a SAILOR 6202 Hand Microphone and an extra SAILOR 6201




Figure B-8: System configuration, SAILOR 6202 Hand Mic. and SAILOR 6201 Handset

B.1.9 How to install a CAN bus and a SAILOR 6204 CSM close to the VHF




Figure B-9: System configuration, CAN bus, SAILOR 6204 CSM, close to the VHF radio

B.1.10 How to install a CAN bus with a SAILOR 6204 CSM not close to the VHF radio




Figure B-10: System configuration, CAN bus, SAILOR 6204 CSM, not close to the VHF radio

B.1.11 How to install a CAN bus with a SAILOR 6204 CSM far from the VHF radio




Figure B-11: System configuration, CAN bus, SAILOR 6204 CSM, far from the VHF radio

B.1.12 How to install a CAN bus with 2 SAILOR 6204 close to the VHF




Figure B-12: System configuration, CAN bus, 2 SAILOR 6204 CSMs, close to VHF radio

B.1.13 How to install a CAN bus and 2 SAILOR 6204 CSM far from the VHF




Figure B-13: System configuration, CAN bus, 2 SAILOR 6204 CSMs, far from VHF radio

B.1.14 How to install a CAN bus with 2 SAILOR 6204 CSMs close to each other




Figure B-14: System configuration: CAN bus, 2 SAILOR 6204 CSMs, close to each other

B.1.15 How to install a CAN bus with 2 SAILOR 6204 CSMs close to VHF on a small bridge




Figure B-15: System configuration: CAN bus, 2 SAILOR 6204 CSMs, close VHF, small bridge

B.1.16 How to install a CAN bus with 2 CSMs in bridge wings




Figure B-16: System configuration: CAN bus, 2 SAILOR 6204 CSMs, in bridge wings

B.1.17 How to install a CAN bus with 3 CSMs in bridge wings





Figure B-17: System configuration: CAN bus, 3 SAILOR 6204 CSMs, in bridge wings

B.1.18 How to install a CAN bus with 4 CSMs in bridge wings



System configurations

Figure B-18: System configuration: CAN bus, 4 SAILOR 6204 CSMs, in bridge wings

B.1.20 How to install a CAN bus with 4 SAILOR 6204 CSMs




Figure B-20: System configuration: CAN bus, 4 SAILOR 6204 CSMs

B.1.21 How to install LAN




Figure B-21: System configuration: Installation of LAN

B.2 Cable requirements

The following cable information relates to the cable numbers in the system configuration drawings on the previous pages.

Cable	Part number	Description	Specification	Remarks
1		Antenna cable	RG124 or better	
2		Handset cable	1 m, spiraled	Part of handset
3	TT-37-131344	Power cable	1.5 m power cable	Included in 406222A
4	Not a T&T part	3-wire power cable, shielded	Depends on length	24 VDC, 4 A
5	406209-941	5 m cable for SAILOR 6207 Connection Box	10-pole LTW cable with screen	Included in Connection Box 406207A
6	406209-940	5 m cable for bulk mount	10-pole LTW cable with screen	
7			2-pole screened cable	
8	406208-941	5 m cable for Connection Box SAILOR 6208	12-pole LTW cable with screen	Included in Connection Box 406208A
9			2-pole screened cable for loudspeaker	
10		0.3 m	Earth connection	
11		3 m	LAN, Ethernet cable	Shielded
12	406204-940	5 m cable for SAILOR 6204 Control Speaker Microphone	12-pole LTW cable for CAN, with screen	Extension cable with LTW plugs in both ends
13		3 m audio cable	Test cable	
14		1.5 m power cable		
15		Cable for SAILOR 6204 Control Speaker Microphone	2.5 m, spiraled	Part of handset
16		Cable for CAN	Screened with twisted pairs, length and size see cable description for <i>Cable 16</i> on page B-29.	Extension cable for CAN bus, see also under cable description for <i>Cable 16</i> on page B-29.

Table B-1: Cable overview

Cable	Part number	Description	Specification	Remarks
17	406204-940	As cable (12). Plug for CTRL is removed and wires connected to connection box	12-pole LTW cable with screen	Extension cable with LTW bulk mount plug
18	Not a T&T part.	Extension cable for power supply. Length: max. 5 m	4 leads, screened wires of 0.5 mm ²	
19	Not a T&T part	Extension cable for power supply for SAILOR 6204.	4 leads, screened wires of 4 mm ² depending on the current and/or cable length.	See cable description.

Table B-1: Cable overview (Continued)

Cable 1

Cable type: Coax cable RG 214 or better.

Cable 2 (Handset, cable included)

SAILOR 6248 VHF Front connector LTW 10-pin, circular male	Signal designation	Signal description
Pin 1	NC	
Pin 2	NC	
Pin 3	NC	
Pin 4	NC	
Pin 5	MIC+	Microphone signal
Pin 6	Earpiece	Earpiece signal
Pin 7	Hook_PTT	Hook/PTT signal
Pin 8	Battery+ (10.8-15.6 VDC)	Battery supply when radio is on
Pin 9	Internal GND = -Battery	Equipment ground
Pin 10	Internal GND = -Battery	Equipment ground

Table B-2: Cable specifications for cable 2

Cable 3 (Power cable, included in 406222A)

Cable type: 3-wire cable.

+ VDC	Red
0 VDC	Blue
ON/OFF	Yellow

Table B-3: Cable specifications for cable 3

Note External power supply input is galvanically isolated from equipment ground reference, i.e. chassis.

Equipment internal power supply reference (-) is at equipment ground reference, i.e. chassis.

Cable 4 (Power cable)

Cable type: 3-wire screened cable. Dimensions depend on the cable length.

Cable 5 (Cable for SAILOR 6207 Connection Box)

Cable type: 10-wire screened cable.

Part number: 406209-941

The cable screen must not touch any metal part of the connection box due to galvanic separation.

SAILOR 6248 VHF ACC connector LTW 10-pin, circular male	Signal designation	Cable pin 406209-941 (5 m)	SAILOR 6207 Connection Box In from VHF	SAILOR 6207 Connection Box Ext. connections	Signal description
Pin 1	NC	Brown	1-1	2(3)-1	Impedance: 600 Ohm. Max. 2 mA at min. level of 2 V (61162-1)
Pin 2	NC	Blue	1-2	2(3)-2	
Pin 3	NC	White	1-3	2(3)-3	Impedance: 600 Ohm. Max. 2 mA at min. level of 2 V (61162-2)
Pin 4	NC	Green	1-4	2(3)-4	
Pin 5	MIC+	Yellow	1-5	2(3)-5	Microphone signal
Pin 6	Earpiece	Grey	1-6	2(3)-6	Earpiece signal
Pin 7	Hook_PTT	Pink	1-7	2(3)-7	Hook/PTT signal
Pin 8	Battery+ (10.8-15.6 VDC)	Red	1-8	2(3)-8	Battery supply when radio is on
Pin 9	Internal GND = -Battery	Black	1-9	2(3)-9	Equipment ground
Pin 10	Internal GND = -Battery	Orange - SCREEN (Drain)	1-10	2(3)-10	Equipment ground
	Cable screen		1-11	2(3)-11	Cable screen must not touch any metal part of the connection box.
			1-12	2(3)-12	Not in use.

Table B-4: Cable specifications for cable 5

Cable 6

Connection cable for bulkhead mount, 5 m.

Part number: 406209-940

Same pin configuration as cable 5.

Cable 7

2-wire screened cable. Not used.

Cable 8 (AUX)

Part number: 406208-941

SAILOR 6248 VHF AUX connector LTW 12-pin, circular male	Signal designation	Cable pin 406208-941 (5 m)	SAILOR 6208 Conn. Box In from VHF	SAILOR 6208 Conn. Box Out of box	SAILOR 6208 Conn. Box Out of box	Signal description	Ships cable 6 twisted pairs overall screen
Pin 1	Shield/GND	Brown	J1-1	J2-1	J3-1	Equipment ground	paired with no. 8
Pin 2	Lo Power	Blue	J1-2	J2-2	J3-2	Low power forced control. Active when connected to ground	paired with no. 3
Pin 3	Not used	White	J1-3	J2-3	J3-3	Impedance: 600 Ohm. Max. 2 mA at min. level of 2 V (61162-2)	paired with no. 2
Pin 4	Not used	Green	J1-4	J2-4	J3-4		paired with no. 7
Pin 5	AUX	Yellow	J1-5	J2-5	J3-5	Open Collector output. Closing on event predefined through service programming ^a	paired with no. 6
Pin 6	DSC Call	Grey	J1-6	J2-6	J3-6	Open Collector output. Closing on incoming DSC call (see footnote)	paired with no. 5
Pin 7	DSC Alarm	Pink	J1-7	J2-7	J3-7	Open Collector output. Closing on incoming DSC alert (see footnote)	paired with no. 4
Pin 8	Battery-	Red	J1-8	J2-8	J3-8	Battery GND	paired with no. 1
Pin 9	Ext. Speaker+	Black	J1-9	J2-9	J3-9	VHF radio external speaker output, nom. 6 W into 8 Ohm	paired with no. 10
Pin 10	Ext. Speaker+	Orange	J1-10	J2-10	J3-10		paired with no. 9
Pin 11	VDR+	Purple	J1-11	J2-11	J3-11	Mixed RX/TX audio output for recording. Galvanically isolated, balanced signal, 0 dBm into 600 Ohm	paired with no. 12
Pin 12	VDR-	Light green	J1-12	J2-12	J3-12		paired with no. 11

Table B-5: Cable specifications for cable 8 (AUX)

a. 24 VDC, max. 100 mA

CAN cable (Cable 8 - CTRL)

Part number: 406208-941

SAILOR 6248 VHF CTRL connector LTW 12-pin, circular male	Signal designation	Cable pin 406208-941 (5 m)	SAILOR 6208 Conn. Box In from VHF	SAILOR 6208 Conn. Box Out of box	SAILOR 6208 Conn. Box Out of box	Signal description	Ships cable 6 twisted pairs overall screen
Pin 1	Shield/GND	Brown	J1-1	J2-1	J3-1	Equipment ground	paired with no. 8
Pin 2	Battery-	Blue	J1-2	J2-2	J3-2	Battery -	paired with no. 3
Pin 3	Battery+	White	J1-3	J2-3	J3-3	10.8-15.6 VDC from VHF radio	paired with no. 2
Pin 4	Battery+	Green	J1-4	J2-4	J3-4	10.8-15.6 VDC from VHF radio	paired with no. 7
Pin 5	CAN_H	Yellow	J1-5	J2-5	J3-5	CAN bus data	paired with no. 6
Pin 6	CAN_L	Grey	J1-6	J2-6	J3-6		paired with no. 5
Pin 7	Battery-	Pink	J1-7	J2-7	J3-7	Battery -	paired with no. 4
Pin 8	ON/OFF from CSM	Red	J1-8	J2-8	J3-8	ON/OFF signal from Control Speaker Microphone	paired with no. 1
Pin 9	RX+	Black	J1-9	J2-9	J3-9	RX telephony (out)	paired with no. 10
Pin 10	RX-	Orange	J1-10	J2-10	J3-10		paired with no. 9
Pin 11	TX+	Purple	J1-11	J2-11	J3-11	TX telephony (in)	paired with no. 12
Pin 12	TX-	Light green	J1-12	J2-12	J3-12		paired with no. 11

Table B-6: Cable specifications for cable 8 (CTRL)

Cable 11

LAN connection.

Ethernet cable with screen and RJ45 shielded plugs.

Pin number	Pin function	Wire color
1	Tx+	white/orange
2	Tx-	orange
3	Rx+	white/green
4	Not connected	blue
5	Not connected	white/blue
6	Rx-	green
7	Not connected	white/brown
8	Not connected	brown

Table B-7: Pin allocation, LAN connector

Cable 16

The CAN bus cable must be of a paired and twisted type designed for the purpose. The CAN bus cable can handle signals up to 100 m away from the VHF to further Control Speaker Microphones (CSM).

Only 1 CSM can be connected to the VHF with a CAN bus cable of max 100 m if the cable dimension is 0.5mm² of each cord. Other combinations with more CSMs must be calculated seriously before installing the cable. If more CSMs are connected, the CAN cable of 0.5mm² can handle the signals up to max. 100 m. The only restriction is the power supply for the connected CSMs.

The voltage drop along the cable increases with the length of the cable. Separate supply cables can be installed in parallel with the CAN cable to reduce voltage drop in long cables. The maximum allowed voltage drop from VHF to CSM is 2 VDC. It means 1 VDC forward and 1 VDC return.

Max current consumption for each CSM is 0.5A.

Formula to calculate DC resistance in a wire:

$$R = 0,017 \times L/a$$

L = length of wire one way, in metre

a = cross section of the wire in mm²

Contact your local dealer for further information for correct installation.

Cable 17: CAN cable for bulk head installation.

Same cable as cable 12, but the plug is removed and the wires are connected to the connection box.

Same pin configuration as cable 8. See *Cable specifications for cable 8 (CTRL)* on page B-28.

Cable 18

Cable between the connection box and terminals to extend the power supply wires.

4 leads, screened wires of 0.5mm². Supply for 6204 CSM for extended CAN BUS connections.

Cable 19

The voltage drop along the cable increases with the length of the cable. Separate supply cables can be installed in parallel with the CAN cable to reduce voltage drop in long cables. The maximum allowed voltage drop from VHF to CSM is 2 VDC. It means 1 VDC forward and 1 VDC return.

The maximum current consumption for each CSM is 0.5 A.

Formula to calculate DC resistance in a wire:

$$R = 0,017 \times L/a$$

L = length of wire one way, in metre

a = cross section of the wire in mm²

For best EMC performance, place the supply cables in parallel with CAN cable

Contact your local dealer for further information for correct installation.

A

ACC Accessories

C

CAN Controller-Area Network. A message based protocol designed to allow microcontrollers and devices to communicate with each other within a vehicle without a host computer.

CTRL Control

L

LAN Local Area Network

LTW LTW Technology is a professional designer and manufacturer of waterproof connectors.

V

VDR Voyage Data Recorder, a data recording system designed for all vessels required to comply with the IMO's International Convention SOLAS Requirements in order to collect data from various sensors on board the vessel.

VHF Very High Frequency

A

ACC connector, 2-12
action line, display, 1-3
adjust
 speaker volume, 3-1
ANT connector, 2-16

B

backlight, 1-1
browse channels, 3-1

C

cable
 CAN, B-28
cable for VHF antenna, 2-16
cable overview, B-23
cable requirements, B-23
CAN cable, B-28
channel
 select, 3-1
 working, 3-1
compass safe distance, 2-2
configuration
 system example, 1-6
configurations
 examples, B-1
 systems, B-1
connector
 ACC, 2-12
 ANT, 2-16
 CTRL, 2-13, 2-14
 ground, 2-16
 VHF antenna, 2-16
contact, 4-1
controls, front plate, 1-2
cradle for 6201, installation, 1-4
CTRL connector, 2-13, 2-14

D

delivery, items included, 2-1

display, 1-3
document number, this manual, -i

E

error messages, 4-1

F

flush mount, 2-6
frequency range, VHF, A-1
front plate, controls, 1-2
fuse
 Power Converter, 4-3
 VHF radio, 4-3

G

ground stud, 2-16
grounding, 2-16

H

hand microphone
 installing, 2-9
handset cradle
 installation, 1-4
how to replace, 4-3

I

installation
 cradle for 6201, 1-4
 desktop, 2-3
 flush mount, 2-6
 handset cradle, 1-4
 mounting bracket, 2-4
 overhead, 2-4
IP rating, A-2

K

keys on front plate, 1-2

knob
 selector, 1-2
 volume, 1-2

L

louder, volume, 3-1

M

manual, document number, -i
mounting, 2-2
 flush mount, 2-6
 with mounting bracket, 2-4

P

power
 fuse, 4-3
 off, 3-1
 on, 3-1
power cable, B-26
Power Converter
 fuse, 4-3
power up, 3-1
private channels, A-2

R

replay, 1-1
 button, 1-2
RF exposure hazards, -iii

S

safety summary, -iii
salt deposits, 4-1
selector knob, 1-2, 3-1
semi duplex, 1-1
service line, display, 1-3
ship ground, 2-16
simplex, 1-1
softer, volume, 3-1
speaker volume, 3-1
specifications, A-1
squelch control, 1-2
support, 4-1

system configuration
 example, 1-6

T

technical data, A-1
temperature
 operational, A-1, A-4
 storage, A-1, A-4

U

UTC time, 1-3

V

VHF
 antenna cable, 2-16
 antenna connector, 2-16
 frequency range, A-1
volume
 louder, 3-1
 softer, 3-1
 speaker, 3-1
Volume knob, 1-2

W

warnings, 4-1
warranty, 4-4
 limitation, -iii
water ingress, A-2
weight, A-1, A-4
working channel, 3-1

98-133233-A